

TAMobile: Add New

Barcode Placement

Good bar code placement provides two important benefits: It helps to easily identify and scan the barcode, and it prevents premature wear, greatly reducing how many times it will need replacing.

Placement Rules

- Every cylinder should have two identical barcode labels
- The labels should be applied to opposite sides of the cylinder
- Barcode labels should not cover DOT specification numbers, or the cylinder serial number



Best Practice for Affixing Barcodes

- Work in pairs:
 - One user should affix the barcode and read off the serial number
 - The other user should scan the barcode and enter the serial number



TAMobile: Add New

Placement Examples

Cylinders with Caps: Labels should be placed on the shoulder as close to the collar as possible



Cylinders with Protective Rings: Labels should be affixed to the vertical support of the protective ring, or centered on the collar

